

Bluetooth Compatibility List



iPhone 6 Plus.....	11
Iphone 6.....	12
Iphone 5s.....	13
Iphone 4s.....	14
Iphone 4.....	15
SAMsungG3608.....	16
SAMsungI9158v.....	17
SAMsungS5 G9009W.....	18
SAMsungGalaxy G7200.....	19
SAMsungS4 9508.....	20
SAMsungS4 GT-I9500.....	21
SAMsungGalaxy Grand 2.....	22
SAMsungA7.....	23
SAMsungB9120.....	24
SAMsungG5309w.....	25
SAMsungSM-G5308W.....	26
SAMsungG3608.....	27
SAMsungI8552.....	28
SAMsung5108.....	29
SAMsungI579.....	30
SAMsungNote3.....	31
SAMsungSM-A3000.....	32
SAMsungGT-I9118.....	33
SAMsungI929.....	34
SAMsung GT-i9082C.....	35
SAMsungG3818.....	36
SAMsung (SAMsung) GALAXY Tab Q T2556.....	37
SAMsungA8.....	38
SAMsungGALAXY J7.....	39
SAMsungG3509i.....	42
SAMsungS3 GT-I9300.....	44
SAMsung I9000.....	45
SAMsung 8552.....	46
SAMsung N7108D.....	47
SAMsung S5360.....	48
SAMsung I809.....	49
SAMsung S5838.....	50
SAMsung I5800.....	51
HTC m8sd.....	52
HTC One E8.....	53
HTC D816t.....	54
HTC M8.....	55
HTC 801e.....	56
HTC D820u.....	60
HTCE9+.....	61

HTCDesire D826d.....	62
HTC Desire 816v.....	63
HTCM9w.....	64
HTC D516t.....	65
SONYZ3 L55t.....	66
SONYZ3.....	67
SONYZ2.....	68
SONYS55t.....	69
SONYCP-V5/B.....	70
SONYZ3 (L55u)	71
SONY NWZ-A15.....	72
SONY E16i.....	73
SONYXperia Z1.....	74
SONYLT26I.....	75
SONYLT18I.....	76
SONY L50t.....	77
SONY ERICSSON Z530I.....	78
SONY ERICSSON W395C.....	79
SONY ERICSSON W908C.....	80
SONY E15i.....	81
MEIZU note2.....	82
MEIZUMX5.....	83
MEIZUMX4 Pro.....	84
MEIZU MX3.....	85
MEIZU MX2.....	86
MI4.....	87
MI3S.....	88
MI2s.....	89
MI1S.....	90
HUAWEIGX1.....	91
HUAWEI 4C.....	92
HUAWEI SONIC.....	93
HUAWEIH30-U10.....	94
HUAWEIGX1.....	95
HUAWEI HONOR(CHE-TL00H).....	96
HUAWEIMate7-TL10.....	97
HUAWEIY635-CL00.....	98
HUAWEIB199.....	99
HUAWEIG521.....	100
HUAWEIC8818.....	101
HUAWEIY518.....	102
HUAWEI HUAWEI Ascend Mate7.....	103
HUAWEIG716.....	104
HONOR 6 (H60-L12).....	105
HUAWEI HONOR6.....	106

HUAWEI C8816.....	107
HUAWEIP7-L00.....	108
HUAWEIP6.....	109
HUAWEIP8.....	110
LENOVO K3 Note.....	111
LENOVO K900.....	112
LENOVO A8.....	113
LENOVOMA388.....	114
LENOVOA828T.....	115
LENOVOA688T.....	116
LENOVOA7600-m.....	117
LENOVOA338T.....	118
LENOVOS820e.....	119
LENOVOS858t.....	120
LENOVOS810T.....	121
LENOVOS860e.....	122
LENOVOA355e.....	123
LENOVOA360e.....	124
LENOVOS850t.....	125
LENOVOA805e.....	126
LENOVOP780.....	127
LENOVOA3800-D.....	128
LENOVOS90u.....	129
LENOVO A8.....	130
LENOVONote8(A938t).....	131
LENOVO K3 Note.....	132
LENOVO A2800-D.....	133
LENOVOA368t.....	134
LENOVOS90-E.....	135
LENOVOS90U.....	136
LENOVOA768T.....	137
LENOVOA516.....	138
LENOVOVIBE Z2.....	139
LENOVO A770E.....	140
LENOVOP70-t.....	141
LENOVO A380E.....	142
LENOVOA858t.....	143
LENOVO A395E.....	144
LENOVOS939.....	145
LENOVO A560.....	146
LENOVO A560.....	147
LENOVOX2-CU.....	148
LENOVOA3860.....	149
LENOVOS960.....	150
LENOVOA358T.....	151

LENOVOA916.....	152
LENOVOS960.....	153
LENOVO TAB 2.....	154
LENOVO A770E.....	155
LENOVO A66t.....	156
LENOVO K900.....	157
ZTEV5.....	158
ZTEB880.....	159
ZTEM901C.....	160
ZTEU968.....	161
ZTE (ZTE) L580.....	162
ZTE 3.....	163
ZTE Q507T.....	164
ZTEQ301C.....	165
ZTEZTE-C V16.....	166
ZTE Q802T.....	167
ZTEQ7.....	168
ZTE (ZTE) > Q805.....	169
ZTE (G718C).....	170
ZTE(ZTE) A880.....	171
ZTEZTE-C V16.....	172
ZTE S291.....	173
ZTE V5 Max(N958St).....	174
ZTEC V18.....	175
ZTES6 (Q5-T)	176
ZTE) L530G.....	177
ZTED&M (Q2S-T).....	178
ZTE U880.....	179
ZTE U930HD.....	180
NUBIA 3 Z7 Max.....	181
NUBIA 3 Z7mini 16G.....	182
NUBIA X6 32G.....	183
NUBIAZ7.....	184
NUBIA (nubia)	184
COOLPADF2.....	185
COOLPADY70-C.....	186
COOLPADX7 8691-00.....	187
COOLPADF1 8297-T01.....	188
COOLPADY80D.....	189
COOLPAD8085Q.....	190
COOLPAD F2 (8675-FHD)	191
COOLPAD 8730L.....	192
COOLPAD 8702D.....	193
COOLPAD 5200S.....	194
COOLPAD 8079.....	195

COOLPAD5316.....	196
COOLPAD 8076D.....	197
COOLPAD(Coolpad) 8017.....	198
COOLPAD(Coolpad) 8076D.....	199
COOLPAD 5217.....	200
COOLPAD(Coolpad) 8713.....	201
COOLPAD 8750.....	202
COOLPAD 7296s.....	203
COOLPAD 4.....	204
COOLPADS6.....	205
COOLPAD 8288.....	206
NOKLA225.....	207
NOKLA215 DS.....	208
NOKLALumia 638.....	209
NOKLAAsha 210.....	210
NOKLAXL 4G (RM-1061).....	211
NOKLAX (RM-980).....	212
NOKLA107.....	213
NOKLA 2060.....	214
NOKLA220.....	215
NOKLA130.....	216
NOKLALumia 1020.....	217
NOKLA1050.....	218
NOKLALumia 930.....	219
NOKLA 526.....	220
NOKLA 520.....	221
MOTO xt319.....	222
MOTO xt531.....	223
MOTO EX200.....	224
MOTO MT720.....	225
MOTO XT320.....	226
MOTO xt553.....	227
MOTO XT800.....	228
MOTO xt532.....	229
MOTO xt889.....	230
MOTO XT885.....	231
MOTO xt882.....	232
MOTO xt685.....	233
MOTO EX226.....	234
MOTO MT870.....	235
MOTO XT316.....	236
MOTO XT300.....	237
MOTO XT800+.....	238
MOTO MT716.....	239
MOTO XT910.....	240

MOTO MT810.....	241
MOTO xt928.....	242
MOTO MT917.....	243
MOTO xt806.....	244
MOTO EX128.....	245
MOTO XT760.....	246
MOTO MT620.....	247
MOTO MT680.....	248
MOTO MT788.....	249
MOTO MT887.....	250
MOTO XT1085.....	251
MOTO XT1077.....	252
MOTOXT1079.....	253
MOTOXT1115.....	254
MOTOXT 1085.....	255
MOTOXT1079.....	256
MOTO MT680.....	257
MOTO XT615.....	258
VIVOXplay 3S.....	259
VIVOX5Pro.....	260
VIVOY27.....	261
VIVOY29L.....	262
VIVOXplay3S X520L.....	263
VIVOY33.....	264
VIVOY13.....	265
VIVOX710L.....	266
VIVOX5L.....	267
LG G2.....	268
LG D859.....	269
LG D728.....	270
LG H818.....	271
LG AKA (H778)	272
LG D802.....	273
LG Nexus 5.....	274
LG C300.....	275
LG T300.....	276
TOUCH u8.....	277
TOUCH u2.....	278
TOUCH c218.....	279
TOUCH ty768.....	280
TOUCH a510.....	281
TOUCH v908.....	282
TOUCH c700.....	283
TOUCH v958.....	284
TOUCH E619.....	285

TOUCH T87+.....	286
TOUCH tou ch 2c.....	287
TOUCH tou ch3es.....	288
TOUCH W98.....	289
TOUCH Tou ch 2.....	290
TOUCH tou ch3c.....	291
TOUCHnibiru H1.....	292
TOUCH T1.....	293
TOUCH Tou ch3.....	294
TOUCH b851.....	295
OPPO R8207.....	296
OPPO X9077.....	297
OPPO 1105.....	298
OPPO N5117.....	299
OPPO 6607.....	300
OPPOR830.....	301
OPPO R8107.....	302
OPPO A31t.....	303
OPPO 3007.....	304
OPPOR7 Plus.....	305
OPPO N3.....	306
OPPO X9070.....	307
PHILIPS x2560.....	314
PHILIPS V387.....	315
PHILIPS E310.....	316
PHILIPS V989.....	317
PHILIPS E160.....	318
PHILIPS W3500.....	319
PHILIPS W8510.....	320
PHILIPS W6500.....	321
PHILIPS S301.....	322
PHILIPS S396.....	323
PHILIPS i928.....	324
PHILIPS X5500.....	325
PHILIPS e320.....	326
PHILIPS S399.....	327
PHILIPS W8568.....	328
PHILIPS S388.....	329
PHILIPS W3550.....	330
PHILIPS S316T.....	331
PHILIPS E130.....	332
PHILIPS E101.....	333
GIONEE M5.....	334
GIONEE W900.....	335
GIONEE GN9006.....	336

GIONEE E7.....	337
GIONEE GN9005.....	338
GIONEE F103.....	339
GIONEE V188.....	340
GIONEE s5.5.....	341
GIONEE V183.....	342
GIONEE x817.....	343
GIONEE V185.....	344
GIONEE A809.....	345
GIONEE A360.....	346
GIONEE GN706L.....	347
GIONEE GN151.....	348
GIONEE GN777E.....	349
GIONEE TD200.....	350
GIONEE Q1.....	351
GIONEE GN810.....	352
GIONEE V100.....	353
GIONEE TD200.....	354
GIONEE GN777.....	355
GIONEE GN150.....	356
GIONEE GN150.....	357
GIONEE GN206.....	358
NEWSMY CM810.....	359
NEWSMY V6.....	360
NEWSMY M29.....	361
NEWSMY k2s.....	362
NEWSMY F520.....	363
NEWSMY C360.....	364
NEWSMY P16.....	365
NEWSMY V9.....	366
NEWSMY L6.....	367
NEWSMY M28.....	368
NEWSMY F29.....	369
NEWSMY V5.....	370
NEWSMY M18.....	371
NEWSMY L66.....	372
NEWSMY L50.....	373
Uniscope U W2014.....	374
Uniscope u2013.....	375
Uniscope US828v.....	376
Uniscope US668 v.....	377
PHILIPS E350.....	378
PHILIPS E180.....	379
PHILIPS W6618.....	380
PHILIPS V8526.....	381

PHILIPS W8578.....	382
PHILIPS x2560.....	383
PHILIPS V387.....	384
PHILIPS E310.....	385
PHILIPS E160.....	386
PHILIPS W8510.....	387
PHILIPS W6500.....	388
PHILIPS S301.....	389
PHILIPS S396.....	390
YITN s139.....	391
YITN S127.....	392
YITN P305.....	393
YITN P11.....	394
YITN S129.....	395
YITN s165.....	396
YITN P2.....	397
YITN P51.....	398
YITN I95.....	399
YITN S136.....	400
M4.....	401
MK150.....	402
C520.....	403
KONKA k5.....	404
KONKA L550.....	405
KONKA L1.....	406
KONKA D557.....	407
KONKA k77.....	408
DOOV V1.....	409
DOOV C9.....	410
DOOV L3.....	411
DOOV L1M.....	412
DOOV S2.....	413
DOOV T60.....	414
DOOV D330.....	415
DOOV D900.....	416
DOOV D800.....	417
DOOV S2Y.....	418
CHANGHONG A100.....	419
CHANGHONG Ga889.....	420
CHANGHONG Ga968.....	421
CHANGHONG z11.....	422
CHANGHONG X9 Plus.....	423
CHANGHONG Ga718.....	424
CHANGHONG G01.....	425
CHANGHONG G01.....	426

CHANGHONG A9800T.....	427
CHANGHONG Ga818.....	428
CHANGHONG 008-3M.....	429
CHANGHONG X5.....	430
CHANGHONG C808.....	431
CHANGHONG X5.....	432
CHANGHONG Z8t.....	433
CHANGHONG A6.....	434
CHANGHONG Ga918.....	435
CHANGHONG C1.....	436
CHANGHONG GA728.....	437
CHANGHONG GA718.....	438
CHANGHONG X6.....	439
CHANGHONG C600.....	440
CHANGHONG C100.....	441
CHANGHONG V70T.....	442
CHANGHONG V1.....	443
Hisense E625T.....	444
Hisense E613M.....	445
Hisense G610M.....	446
Hisense E621T.....	447
Hisense I639M.....	448
Hisense HS-EG980.....	449
Hisense hs-x1.....	450
Hisense E601M.....	451
Hisense HS-H800T.....	452
Hisense E260T+.....	453
Hisense E100T.....	454
Hisense H910.....	455
Hisense HS-X6T.....	456
Hisense I632M.....	457
Hisense I632M.....	458
Hisense HS-EG958.....	459

iPhone 6 Plus


iphone	iPhone 6 Plus	HFP/HSP	PAIR	√
			AUTO CONNECT	√
			DISCONNECT	√
			DAIL NUMBER	√
			DAIL DTMF	√
			CALLER ID	√
			REJECT INCOMMING CALL	√
			OGGLET	√
		AVRCP	PLAY/PAUSE	√
			STOP	√
			STOP	√
			FORWARD	√
		PHONE BOOK	PBAP	√
			AT COMMAND	√
CALL LIST	RECEIVED CALL		√	
	MISSED CALL	√		
	DAILED CALL	√		



Iphone 6

.. iphone	iphone 6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONE BOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Iphone 5s

iphone	iphone 5s	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONE BOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Iphone 4s

iphone	iphone 4s	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Iphone 4

iphone	iphone 4	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGG3608

SAMSUNG (SAMSUNG)	SAMSUNGG3608	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGI9158v

SAMSUNG (SAMSUNG)	SAMSUNGI9158v	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG S5 G9009W

SAMSUNG (SAMSUNG)	SAMSUNG S5 G9009W	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGGalaxy G7200

SAMSUNG	SAMSUNGGalaxy G7200	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGs4 9508

SAMSUNG	SAMSUNGs4 9508	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGS4 GT-I9500

SAMSUNG	SAMSUNG S4 GT-I9500	HPP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMsungGalaxy Grand 2

SAMSUNG	SAMSUNGGalaxy Grand 2	HF/HS 发	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOO K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGA7

SAMSUNG	SAMSUNGA7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGB9120

SAMSUNG	SAMSUNGB9120	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGG5309w


SAMSUNG	SAMSUNGG5309w	HFP/HSP	HFP /HS P	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGSM-G5308W


SAMSUNG	SAMSUNGSM-G5308W	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGG3608

SAMSUNG	SAMSUNGG3608	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG	SAMSUNGI8552	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG5108


SAMSUNG	SAMSUNG5108	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG	SAMSUNGI579	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGNote3

SAMSUNG	SAMSUNGNote3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGSM-A3000

SAMSUNG	SAMSUNGSM-A3000	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGGT-I9118

SAMSUNG	SAMSUNGGT-I9118	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGI929

SAMSUNG	SAMSUNGI929	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNG GT-i9082C

SAMSUNG	SAMSUNG GT-i9082C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNGG3818

SAMSUNG	SAMSUNGG3818	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNG (SAMSUNG) GALAXY Tab Q T2556

SAMSUNG	SAMSUNG (SAMSUNG) GALAXY Tab Q T2556	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGA8

SAMSUNG	SAMSUNGA8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMsung GALAXY J7

SAMSUNG	SAMSUNG GALAXY J7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGE7000

SAMSUNG	SAMSUNGE7000	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGW999

SAMSUNG	SAMSUNGW999	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGG3509i

SAMSUNG	SAMSUNGG3509i	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGNote3

SAMSUNG	SAMSUNGNote3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNGS3 GT-I9300

SAMSUNG	SAMSUNG S3 GT-I9300	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG I9000


SAMSUNG	SAMSUNG I9000	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG 8552


SAMSUNG	SAMSUNG8552	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG N7108D


SAMSUNG	SAMSUNG N7108D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG	SAMSUNG S5360	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNG I809

SAMSUNG	SAMSUNG I809	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SAMSUNG S5838

SAMSUNG	SAMSUNG S5838	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SAMSUNG I5800

SAMSUNG	SAMSUNG I5800	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC m8sd

HTC m8sd	m8sd	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC One E8

HTC	HTC One E8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HTC D816t

HTC	HTC D816t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HTC M8

HTC	HTCM8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC 801e

HTC	HTC801e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HTCE9 (E9w)

HTC	HTCE9 (E9w)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HTC One M9w

HTC	HTC One M9w	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC626w

HTC	HTC626w	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC D820u

HTC	HTCD820u	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTCE9+

HTC	HTCE9+	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTCDesire D826d

HTC	HTCDesire D826d	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC Desire 816v

HTC	HTC Desire 816v	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTCM9w

HTC	HTCM9w	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HTC D516t

HTC	HTC D516t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYZ3 L55t

SONY (SONY)	SONYZ3 L55	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYZ3

SONY	SONYZ3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYZ2

SONY	SONYZ2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYS55t

SONY	SONYS55t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONYCP-V5/B

SONY	SONYCP-V5/B	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONYZ3 (L55u)

SONY	SONYZ3 (L55u)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONY NWZ-A15

SONY	SONY NWZ-A15	HFP/HSP	PAIR	√
			AUTO CONNECT	√
			DISCONNECT	√
			DAIL NUMBER	√
			DAIL DTMF	√
			CALLER ID	√
			REJECT INCOMMING CALL	√
			OGGLET	√
		AVRCP	PLAY/PAUSE	√
			STOP	√
	STOP		√	
	FORWARD		√	
		PHONEBOOK	PBAP	√
			AT COMMAND	√
CALL LIST		RECEIVED CALL	√	
		MISSED CALL	√	
		DAILED CALL	√	


SONY E16i

SONY	SONY E16i	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONYXperia Z1

SONY	SONYXperia Z1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYLT26I

SONY	SONYLT26I	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONYLT18I

SONY	SONYLT18I	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONY L50t

SONY	SONY L50t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONY ERICSSON Z530I

SONY ERICSSON	SONY ERICSSON Z530I	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONY ERICSSON W395C

SONY ERICSSON	SONY ERICSSON W395C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


SONY ERICSSON W908C

SONY ERICSSON	SONY ERICSSON W908C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SONY E15i

SONY	SONY E15i	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MEIZU note2

MEIZU (MEIZU)	MEIZU note2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MEIZUMX5

MEIZU (MEIZU)	MEIZUMX5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MEIZUMX4 Pro

MEIZU (MEIZU)	MEIZUMX4 Pro	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MEIZU MX3

MEIZU	MEIZU MX3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MEIZU MX2

MEIZU	MEIZU <u>MX2</u>	HFP/HSP	PAIR	√
			AUTO CONNECT	√
			DISCONNECT	√
			DAIL NUMBER	√
			DAIL DTMF	√
			CALLER ID	√
			REJECT INCOMMING CALL	√
			OGGLET	√
		AVRCP	PLAY/PAUSE	√
			STOP	√
	STOP		√	
	FORWARD		√	
		PHONEBOOK	PBAP	√
			AT COMMAND	√
CALL LIST		RECEIVED CALL	√	
		MISSED CALL	√	
		DAILED CALL	√	

MI4

MI (MI)	MI4	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MI3S

MI	MI3S	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MI2s

MI	MI2s	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MI1S

MI	MI1S	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIGX1

HUAWEI	HUAWEIGX1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEI 4C

HUAWEI	HUAWEI 4C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEI SONIC

HUAWEI	HUAWEI SONIC	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIH30-U10

HUAWEI	HUAWEIH30-U10	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIGX1

HUAWEI	HUAWEIGX1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEI HONOR(CHE-TL00H)

HUAWEI	HUAWEI HONOR (CHE-TL00H)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIMate7-TL10

HUAWEI	HUAWEIMate7-TL10	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HUAWEIY635-CL00

HUAWEI	HUAWEIY635-CL00	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIB199

HUAWEI	HUAWEIB199	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HUAWEIG521

HUAWEI	HUAWEIG521	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HUAWEIC8818

HUAWEI	HUAWEIC8818	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIY518

HUAWEI	HUAWEIY518	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HUAWEI HUAWEI Ascend Mate7

HUAWEI	HUAWEI HUAWEI Ascend Mate7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HUAWEIG716

HUAWEI	HUAWEIG716	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


HONOR 6 (H60-L12)

HUAWEI	HONOR 6 (H60-L12)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HUAWEI HONOR6

HUAWEI	HUAWEI HONOR6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			

HUAWEI C8816

HUAWEI	HUAWEI C8816	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HUAWEIP7-L00

HUAWEI (HUAWEI)	HUAWEIP7-L00	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

HUAWEIP6

HUAWEI (HUAWEI)	HUAWEIP6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


HUAWEIP8

HUAWEI (HUAWEI)	HUAWEIP8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVO K3 Note

LENOVO	LENOVO K3 Note	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO K900

LENOVO	LENOVO K900	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVO A8

LENOVO	LENOVO A8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOMA388

LENOVO	LENOVOMA388	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA828T

LENOVO	LENOVOA828T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA688T

LENOVO	LENOVOA688T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVOA7600-m

LENOVO	LENOVOA7600-m	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVOA338T

LENOVO	LENOVOA338T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS820e

LENOVO	LENOVOS820e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS858t

LENOVO	LENOVOS858t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS810T

LENOVO	LENOVOS810T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS860e

LENOVO	LENOVOS860e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA355e

LENOVO	LENOVOA355e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA360e

LENOVO	LENOVOA360e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS850t

LENOVO	LENOVOS850t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA805e

LENOVO	LENOVOA805e	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOP780

LENOVO	LENOVOP780	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVOA3800-D

LENOVO	LENOVOA3800-D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS90u

LENOVO	LENOVOS90u	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A8

LENOVO	LENOVO A8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVONote8(A938t)

LENOVO	LENOVONote8(A938t)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO K3 Note

LENOVO	LENOVO K3 Note	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A2800-D

LENOVO	LENOVO A2800-D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA368t

LENOVO	LENOVOA368t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS90-E

LENOVO	LENOVOS90-E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVOS90U

LENOVO	LENOVOS90U	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA768T

LENOVO	LENOVOA768T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA516

LENOVO	LENOVOA516	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVOVIBE Z2

LENOVO	LENOVOVIBE Z2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A770E

LENOVO	LENOVO A770E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOP70-t

LENOVO	LENOVOP70-t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A380E

LENOVO	LENOVO A380E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA858t

LENOVO	LENOVOA858t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A395E

LENOVO	LENOVO A395E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS939

LENOVO	LENOVOS939	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A560

LENOVO	LENOVO A560	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A560

LENOVO	LENOVO A560	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOX2-CU

LENOVO	LENOVOX2-CU	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA3860

LENOVO	LENOVOA3860	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS960

LENOVO	LENOVOS960	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA358T

LENOVO	LENOVOA358T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOA916

LENOVO	LENOVOA916	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVOS960

LENOVO	LENOVOS960	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO TAB 2

LENOVO	LENOVO TAB 2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LENOVO A770E

LENOVO	LENOVO A770E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO A66t

LENOVO	LENOVO A66t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LENOVO K900

LENOVO	LENOVO K900	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTEV5

ZTE	ZTEV5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTE	ZTEB880	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTEM901C

ZTE	ZTEM901C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE	ZTEU968	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE (ZTE) L580

ZTE	ZTE (ZTE) L580	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE	ZTE 3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE Q507T

ZTE	ZTE Q507T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTEQ301C

ZTE	ZTEQ301C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTEZTE-C V16

ZTE	ZTEZTE-C V16	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE Q802T

ZTE	ZTE Q802T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTEQ7

ZTE	ZTEQ7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTE (ZTE) > Q805

ZTE	ZTE (ZTE) > Q805	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE (G718C)

ZTE	ZTE (G718C)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE(ZTE) A880

ZTE	ZTE(ZTE) A880	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTEZTE-C V16

ZTE	ZTEZTE-C V16	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE S291

ZTE	ZTE S291	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
			CALL LIST	RECEIVED CALL	√
MISSED CALL	√				
DAILED CALL	√				

ZTE V5 Max(N958St)

ZTE	ZTE V5 Max(N958St)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTEC V18

ZTE	ZTEC V18	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTES6 (Q5-T)

ZTE	ZTES6 (Q5-T)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTE) L530G

ZTE	ZTE L530G	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


ZTED&M (Q2S-T)

ZTE	ZTED&M (Q2S-T)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE U880

ZTE	ZTE U880	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

ZTE U930HD

ZTE	ZTE U930HD	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NUBIA 3 Z7 Max

NUBIA (nubia)	NUBIA 3 Z7 Max	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NUBIA 3 Z7mini 16G

NUBIA (nubia)	NUBIA 3 Z7mini 16G	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NUBIA X6 32G

NUBIA (nubia)	NUBIA X6 32G	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NUBIAZ7


NUBIA (nubia)	NUBIAZ7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPADF2

COOLPAD	COOLPADF2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPADY70-C

COOLPAD	COOLPADY70-C	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD	COOLPADX7 8691-00	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD	COOLPADF1 8297-T01	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPADY80D

COOLPAD	COOLPADY80D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD8085Q

COOLPAD	COOLPAD8085Q	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD F2 (8675-FHD)

COOLPAD	COOLPAD F2 (8675-FHD)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPAD 8730L

COOLPAD	COOLPAD 8730L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPAD 8702D

COOLPAD	COOLPAD 8702D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD 5200S

COOLPAD	COOLPAD 5200S	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPAD 8079

COOLPAD	COOLPAD 8079	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD5316

COOLPAD	COOLPAD5316	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPAD 8076D

COOLPAD	COOLPAD 8076D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD(Coolpad) 8017

COOLPAD	COOLPAD(Coolpad) 8017	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD(Coolpad) 8076D

COOLPAD	COOLPAD(Coolpad) 8076D	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD 5217

COOLPAD	COOLPAD 5217	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD(Coolpad) 8713

COOLPAD	COOLPAD(Coolpad) 8713	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD 8750


COOLPAD	COOLPAD 8750	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SHENZHEN GOODOCOM Co.,LTD

COOLPAD 7296s

COOLPAD	COOLPAD 7296s	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


COOLPAD 4

COOLPAD (Coolpad)	COOLPAD 4	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPADS6

COOLPAD (Coolpad)	COOLPADS6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

COOLPAD 8288

COOLPAD	COOLPAD 8288	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA225


NOKLA (NOKIA)	NOKLA225	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SHENZHEN GOODOCOM Co.,LTD


NOKLA215 DS

NOKLA (NOKIA)	NOKLA215 DS	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NOKLALumia 638

NOKIA (NOKIA)	NOKLALumia 638	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NOKLAAsha 210

NOKIA (NOKIA)	NOKLAAsha 210	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLAXL 4G (RM-1061)

NOKIA (NOKIA)	NOKLAXL 4G (RM-1061)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLAX (RM-980)

NOKIA (NOKIA)	NOKLAX (RM-980)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA107

NOKLA (NOKIA)	NOKLA107	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA 2060

NOKLA (NOKIA)	NOKLA 2060	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA220

NOKLA (NOKIA)	NOKLA220	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA130

NOKLA (NOKIA)	NOKLA130	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLALumia 1020

NOKIA (NOKIA)	NOKLALumia 1020	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA1050


.. NOKLA (NOKIA)	NOKLA1050	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

.. NOKLA (NOKIA)	NOKLALumia 930	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NOKLA 526

NOKLA	NOKLA 526	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NOKLA 520

NOKLA	NOKLA 520	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt319

MOTO	MOTO xt319	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt531

MOTO	MOTO xt531	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO EX200

MOTO	MOTO EX200	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT720

MOTO	MOTO MT720	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO XT320

MOTO	MOTO XT320	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt553

MOTO	MOTO xt553	HPP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT800

MOTO	MOTO XT800	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt532

MOTO	MOTO xt532	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt889

MOTO	MOTO xt889	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO XT885

MOTO	MOTO XT885	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt882

MOTO	MOTO xt882	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO xt685

MOTO	MOTO xt685	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO EX226

MOTO	MOTO EX226	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO MT870

MOTO	MOTO MT870	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO XT316

MOTO	MOTO XT316	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT300

MOTO	MOTO XT300	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO XT800+

MOTO	MOTO XT800+	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT716


MOTO	MOTO MT716	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT910

MOTO	MOTO XT910	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT810

MOTO	MOTO MT810	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO	MOTO xt928	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO MT917

MOTO	MOTO MT917	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO xt806


MOTO	MOTO xt806	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO EX128


MOTO	MOTO EX128	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

SHENZHEN GOODOCOM Co.,LTD

MOTO XT760

MOTO	MOTO XT760	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT620

MOTO	MOTO MT620	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT680

MOTO	MOTO MT680	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO MT788

MOTO	MOTO MT788	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTO MT887

MOTO	MOTO MT887	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT1085

MOTO	MOTO XT108	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT1077

MOTO	MOTO XT1077	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTOXT1079

MOTO	MOTOXT1079	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTOXT1115

MOTO	MOTOXT1115	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTOXT 1085

MOTO	MOTOXT 1085	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


MOTOXT1079

MOTO	MOTOXT1079	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO MT680

MOTO	MOTO MT680	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

MOTO XT615

MOTO	MOTO XT615	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOXplay 3S

VIVO	VIVOXplay 3S	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOX5Pro

VIVO	VIVOX5Pro	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOY27

VIVO	VIVOY27	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


VIVOY29L

VIVO	VIVOY29L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOXplay3S X520L

VIVO	VIVOXplay3S X520L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOY33

VIVO	VIVOY33	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

VIVOY13

VIVO	VIVOY13	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


VIVOX710L


VIVO	VIVOX710L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


VIVOX5L

VIVO	VIVOX5L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG G2

LG	LG G2	HFP/HSP	PAIR	√
			AUTO CONNECT	√
			DISCONNECT	√
			DAIL NUMBER	√
			DAIL DTMF	√
			CALLER ID	√
			REJECT INCOMMING CALL	√
			OGGLET	√
		AVRCP	PLAY/PAUSE	√
			STOP	√
			STOP	√
			FORWARD	√
		 PHONEBOOK K	PBAP	√
			AT COMMAND	√
CALL LIST	RECEIVED CALL		√	
	MISSED CALL		√	
	DAILED CALL		√	

LG	LG D859	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LG	LG D728	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG H818

LG	LG H818	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG AKA (H778)

LG	LG AKA (H778)	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG	LG D802	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


LG Nexus 5

LG	LG Nexus 5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG C300

LG	LG C300	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

LG T300

LG	LG T300	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH u8

TOUCH	TOUCH u8	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH u2

TOUCH	TOUCH u2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH c218

TOUCH	TOUCH c218	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH ty768

TOUCH	TOUCH ty768	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH a510


TOUCH	TOUCH a510	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH v908

TOUCH	TOUCH v908	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH c700

TOUCH	TOUCH c700	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH	TOUCH v958	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH E619

TOUCH	TOUCH E619	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH T87+

TOUCH	TOUCH T87+	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH touch 2c

TOUCH	TOUCH touch 2c	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH tou ch3es

TOUCH	TOUCH tou ch3es	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH W98

TOUCH	TOUCH W98	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH Tou ch 2

TOUCH	TOUCH Tou ch 2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH tou ch3c

TOUCH	TOUCH tou ch3c	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCHnibiru H1

TOUCH	TOUCHnibiru H1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH T1

TOUCH	TOUCH T1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


TOUCH Tou ch3

TOUCH	TOUCH Tou ch3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

TOUCH b851

TOUCH	TOUCH b851	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO R8207

OPPO	OPPO R8207	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


OPPO X9077

OPPO	OPPO X9077	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO 1105

OPPO	OPPO 1105	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO N5117

OPPO	OPPO N5117	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


OPPO 6607

OPPO	OPPO 6607	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


OPPOR830

OPPO	OPPOR830	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


OPPO R8107

OPPO	OPPO R8107	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO A31t

OPPO	OPPO A31t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO 3007

OPPO	OPPO 3007	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPOR7 Plus

OPPO	OPPOR7 Plus	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

OPPO N3

OPPO	OPPO N3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


OPPO X9070

OPPO	OPPOX9070	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS V8526

PHILIPS	PHILIPS V8526	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS E180

PHILIPS	PHILIPS E180	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS E180

PHILIPS	PHILIPS E180	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS 1999

PHILIPS	PHILIPS 1999	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS W8578

PHILIPS	PHILIPS W8578	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E350

PHILIPS	PHILIPS E350	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS x2560

PHILIPS	PHILIPS x2560	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS V387

PHILIPS	PHILIPS V387	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E310

PHILIPS	PHILIPS E310	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS V989

PHILIPS	PHILIPS V989	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E160

PHILIPS	PHILIPS E160	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W3500

PHILIPS	PHILIPS W3500	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W8510

PHILIPS	PHILIPS W8510	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W6500

PHILIPS	PHILIPS W6500	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS S301

PHILIPS	PHILIPS S301	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS S396

PHILIPS	PHILIPS S396	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS i928

PHILIPS	PHILIPS i928	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS X5500

PHILIPS	PHILIPS X5500	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS e320

PHILIPS	PHILIPS e320	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS S399

PHILIPS	PHILIPS S399	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W8568

PHILIPS	PHILIPS W8568	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS S388

PHILIPS	PHILIPS S388	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS W3550

PHILIPS	PHILIPS W3550	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS S316T

PHILIPS	PHILIPS S316T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E130

PHILIPS	PHILIPS E130	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E101

PHILIPS	PHILIPS E101	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE M5

PHILIPS	GIONEE M5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE W900

PHILIPS	GIONEE W900	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE GN9006

PHILIPS	GIONEE GN9006	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE E7

PHILIPS	GIONEE E7	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN9005

PHILIPS	GIONEE GN9005	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE F103


PHILIPS	GIONEE F103	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE V188

PHILIPS	GIONEE V188	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS	GIONEE s5.5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE V183


PHILIPS	GIONEE V183	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS	GIONEE x817	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE V185

PHILIPS	GIONEE V185	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE A809

PHILIPS	GIONEE A809	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE A360

PHILIPS	GIONEE A360	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN706L

PHILIPS	GIONEE GN706L	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN151

PHILIPS	GIONEE GN151	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN777E

PHILIPS	GIONEE GN777E	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE TD200

PHILIPS	GIONEE TD200	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE Q1

PHILIPS	GIONEE Q1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN810

PHILIPS	GIONEE GN810	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE V100

PHILIPS	GIONEE V100	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE TD200

PHILIPS	GIONEE TD200	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN777

PHILIPS	GIONEE GN777	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


GIONEE GN150

PHILIPS	GIONEE GN150	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE GN150

PHILIPS	GIONEE GN150	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

GIONEE GN206

PHILIPS	GIONEE GN206	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NEWSMY CM810

NEWSMY	NEWSMY CM810	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY V6

NEWSMY	NEWSMY V6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NEWSMY M29

NEWSMY	NEWSMY M29	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NEWSMY k2s

NEWSMY	NEWSMY k2s	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY F520

NEWSMY	NEWSMY F520	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY C360

NEWSMY	NEWSMY F520	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY P16

NEWSMY	NEWSMY P16	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY V9

NEWSMY	NEWSMY V9	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY L6

NEWSMY	NEWSMY L6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY M28

NEWSMY	NEWSMY M28	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY F29

NEWSMY	NEWSMY F29	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY V5

NEWSMY	NEWSMY V5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NEWSMY M18

NEWSMY	NEWSMY M18	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


NEWSMY L66


NEWSMY	NEWSMY L66	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

NEWSMY L50


NEWSMY	NEWSMY L50	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Uniscope U W2014


Uniscope	Uniscope U W2014	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Uniscope	Uniscope u2013	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Uniscope US828v

Uniscope	Uniscope US828v	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Uniscope US668 v

Uniscope	Uniscope US668 v	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E350

PHILIPS	PHILIPS E350	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E180

PHILIPS	PHILIPS 1999	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W6618

PHILIPS	PHILIPS W6618	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS V8526

PHILIPS	PHILIPS V8526	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W8578

PHILIPS	PHILIPS W8578	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS x2560

PHILIPS	PHILIPS x2560	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS V387

PHILIPS	PHILIPS V387	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E310

PHILIPS	PHILIPS E310	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS E160

PHILIPS	PHILIPS E160	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W8510

PHILIPS	PHILIPS W8510	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS W6500

PHILIPS	PHILIPS W6500	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


PHILIPS S301

PHILIPS	PHILIPS S301	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

PHILIPS S396

PHILIPS	PHILIPS S396	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


YITN	YITN s139	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN	YITN S127	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN P305


YITN	YITN P305	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN P11


YITN	YITN P11	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN S129


YITN	YITN S129	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN	YITN s165	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN P2

YITN	YITN P2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN P51

YITN	YITN P51	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

YITN 195

YITN	YITN 195	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


YITN S136

YITN	YITN S136	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

M4

Meitu	M4	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Meitu	MK150	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Meitu	C520	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


KONKA k5

Konka	KONKA k5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

KONKA L550

Konka	KONKA L550	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


KONKA L1

Konka	KONKA L1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


KONKA D557

Konka	KONKA D557	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


KONKA k77

Konka	KONKA k77	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV V1

DOOV	DOOV V1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV C9

DOOV	DOOV C9	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


DOOV L3

DOOV	DOOV L3	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV L1M

DOOV	DOOV L1M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV S2

DOOV	DOOV S2	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV T60

DOOV	DOOV T60	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


DOOV D330

DOOV	DOOV D330	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

DOOV D900

DOOV	DOOV D900	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


DOOV D800

DOOV	DOOV D800	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


DOOV S2Y

DOOV	DOOV S2Y	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG A100

Changhong	CHANGHONG A100	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Ga889

Changhong	CHANGHONG Ga889	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Ga968

Changhong	CHANGHONG Ga968	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG z11

Changhong	CHANGHONG z11	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG X9 Plus

Changhong	CHANGHONG X9 Plus	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Ga718

Changhong	CHANGHONG Ga718	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
		 <p>长虹 GA718 全能待机王 4800mAh超大电池 充电宝功能 注意你选中了超能版</p>	PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG G01

Changhong	CHANGHONG G01	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG G01

Changhong	CHANGHONG G01	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG A9800T

Changhong	CHANGHONG A9800T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Ga818

Changhong	CHANGHONG Ga818	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG 008-3M

Changhong	CHANGHONG 008-3M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG X5

Changhong	CHANGHONG X5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG C808

Changhong	CHANGHONG C808	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG X5

Changhong	CHANGHONG X5	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Z8t

Changhong	CHANGHONG Z8t	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG A6

Changhong	CHANGHONG A6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG Ga918

Changhong	CHANGHONG Ga918	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG C1

Changhong	CHANGHONG C1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG GA728

Changhong	CHANGHONG GA728	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

CHANGHONG GA718

Changhong	CHANGHONG GA718	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG X6

Changhong	CHANGHONG X6	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


CHANGHONG C600

Changhong	CHANGHONG C600	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

CHANGHONG C100

Changhong	CHANGHONG C100	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL	√			
	DAILED CALL	√			


CHANGHONG V70T

Changhong	CHANGHONG V70T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

CHANGHONG V1

Changhong	CHANGHONG V1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK K	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense E625T

Hisense	Hisense E625T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Hisense E613M

Hisense	Hisense E613M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense G610M

Hisense	Hisense G610M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense E621T

Hisense	Hisense E621T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense I639M

Hisense	Hisense I639M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense HS-EG980

Hisense	Hisense HS-EG980	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense hs-x1

Hisense	Hisense hs-x1	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense E601M

Hisense	Hisense E601M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense HS-H800T

Hisense	Hisense HS-H800T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense E260T+

Hisense	Hisense E260T+	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense E100T

Hisense	Hisense E100T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Hisense H910

Hisense	Hisense H910	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Hisense HS-X6T

Hisense	Hisense HS-X6T	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		


Hisense I632M

Hisense	Hisense I632M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Hisense I632M

Hisense	Hisense I632M	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		

Hisense HS-EG958

Hisense	Hisense HS-EG958	HFP/HSP	PAIR	√	
			AUTO CONNECT	√	
			DISCONNECT	√	
			DAIL NUMBER	√	
			DAIL DTMF	√	
			CALLER ID	√	
			REJECT INCOMMING CALL	√	
			OGGLET	√	
		AVRCP	PLAY/PAUSE	√	
			STOP	√	
			STOP	√	
			FORWARD	√	
			PHONEBOOK	PBAP	√
				AT COMMAND	√
CALL LIST	RECEIVED CALL		√		
	MISSED CALL		√		
	DAILED CALL		√		